

VI.6.3-PPDUTIL-SYSTEM-DELTYPE PROGRAM PPDUTIL COMMAND DELTYPE

Purpose

Command DELTYPE deletes daily data types in the Preprocessor Data Base.

A data type cannot be deleted if there are any stations defined with the data type.

Input Data

<u>Card</u>	<u>Field</u>	<u>Format</u>	<u>Contents</u>
1	1		'@DELTYPE'
2	1-n	A4	Daily data types to be deleted <u>1/</u> <u>2/</u>

Notes:

- 1/ Valid daily data types are PP24, PPVR, TM24, TAVR, TF24, MDR6, PPSR and EA24.
- 2/ A continuation card is expected when an ampersand (&) is found on the card to be continued.

Example

```
@DELTYPE
PPSR MDR6
```